




Exploded diagram and spare parts list (CW197/G592-Refrigerator) (G593-Freezer)

Machine	Explode	Code	Description
CW197/G592/G593 - Polar Gastro Single Door Upright	1	AB948	Hinge
CW197/G592/G593 - Polar Gastro Single Door Upright	2	AH322	Front Panel for CW197
CW197/G592/G593 - Polar Gastro Single Door Upright	2	AB924	Front Panel for G592 G593
CW197/G592/G593 - Polar Gastro Single Door Upright	3	AB352	Lock
CW197/G592/G593 - Polar Gastro Single Door Upright	4	AB363	Thermostat
CW197/G592/G593 - Polar Gastro Single Door Upright	5	AB308	Main Switch
CW197/G592/G593 - Polar Gastro Single Door Upright	6	AB888	Door Switch
CW197/G592/G593 - Polar Gastro Single Door Upright	7	AH314	Up Hinge Right for CW197
CW197/G592/G593 - Polar Gastro Single Door Upright	7	AH315	Up Hinge Right for G592 G593
CW197/G592/G593 - Polar Gastro Single Door Upright	8	AB346	Door Spring
CW197/G592/G593 - Polar Gastro Single Door Upright	9		Glass Door for CW197
CW197/G592/G593 - Polar Gastro Single Door Upright	9		Door (Door with handle) for G592 G593
CW197/G592/G593 - Polar Gastro Single Door Upright	10	AB930	Gasket
CW197/G592/G593 - Polar Gastro Single Door Upright	11	AH316	Down Hinge Axis Jacket for CW197
CW197/G592/G593 - Polar Gastro Single Door Upright	11	AB287	Down Hinge Axis Jacket for G592 G593
CW197/G592/G593 - Polar Gastro Single Door Upright	12		Support
CW197/G592/G593 - Polar Gastro Single Door Upright	13	AB982	Water Box
CW197/G592/G593 - Polar Gastro Single Door Upright	14		Water Pan Guide Right
CW197/G592/G593 - Polar Gastro Single Door Upright	14A		Water Pan Guide Left
CW197/G592/G593 - Polar Gastro Single Door Upright	15	AE824	Castors (SET 4)
CW197/G592/G593 - Polar Gastro Single Door Upright	15	AB328	Braked Castors
CW197/G592/G593 - Polar Gastro Single Door Upright	15	AB856	Standard Castor
CW197/G592/G593 - Polar Gastro Single Door Upright	16	AA634	Drain Pipe Nut
CW197/G592/G593 - Polar Gastro Single Door Upright	17	AB356	Down Hinge Axis
CW197/G592/G593 - Polar Gastro Single Door Upright	18	AH320	Down Hinge for CW197
CW197/G592/G593 - Polar Gastro Single Door Upright	18	AB897	Down Hinge for G592 G593
CW197/G592/G593 - Polar Gastro Single Door Upright	19	AA637	Drain Pipe
CW197/G592/G593 - Polar Gastro Single Door Upright	20	AA638	Drain Pipe Cover
CW197/G592/G593 - Polar Gastro Single Door Upright	21		Body for CW197 G592
CW197/G592/G593 - Polar Gastro Single Door Upright	21		Body for G593
CW197/G592/G593 - Polar Gastro Single Door Upright	22	AB413	Guide Left
CW197/G592/G593 - Polar Gastro Single Door Upright	22A	AB412	Guide Right
CW197/G592/G593 - Polar Gastro Single Door Upright	23	AB411	Shelf
CW197/G592/G593 - Polar Gastro Single Door Upright	26	AB953	Probe Padding
CW197/G592/G593 - Polar Gastro Single Door Upright	27	AA639	Sensor Fixed Clip
CW197/G592/G593 - Polar Gastro Single Door Upright	28	AC614	Sensor
CW197/G592/G593 - Polar Gastro Single Door Upright	29		Circle Fan Cover
CW197/G592/G593 - Polar Gastro Single Door Upright	30	AH301	Circle Fan
CW197/G592/G593 - Polar Gastro Single Door Upright	31	AB916	Screen Filter
CW197/G592/G593 - Polar Gastro Single Door Upright	32	AH302	Unit Board
CW197/G592/G593 - Polar Gastro Single Door Upright	33	AA658	Basket Guard Grilles

Exploded diagram and spare parts list (CW197/G592-Refrigerator) (G593-Freezer)

CW197/G592/G593 - Polar Gastro Single Door Upright	34	AE831	Discharge Tube for CW197 G592
CW197/G592/G593 - Polar Gastro Single Door Upright	34	AH310	Discharge Tube for G593
CW197/G592/G593 - Polar Gastro Single Door Upright	37	AG554	Plug
CW197/G592/G593 - Polar Gastro Single Door Upright	38	AH303	Suction Pipe for CW197 G592
CW197/G592/G593 - Polar Gastro Single Door Upright	38	AH304	Suction Pipe for G593
CW197/G592/G593 - Polar Gastro Single Door Upright	40	AB865	Compressor(R134a) for G592
CW197/G592/G593 - Polar Gastro Single Door Upright	40	AB863	Compressor(R404a) for G593
CW197/G592/G593 - Polar Gastro Single Door Upright	40	AG014	Compressor(R600a) for CW197 G592
CW197/G592/G593 - Polar Gastro Single Door Upright	40	AH014	Compressor(R290) for G593
CW197/G592/G593 - Polar Gastro Single Door Upright	41	AB309	Condenser Fan for CW197 G592
CW197/G592/G593 - Polar Gastro Single Door Upright	41	AB312	Condenser Fan for G593
CW197/G592/G593 - Polar Gastro Single Door Upright	42	AB869	Condenser for CW197 G592
CW197/G592/G593 - Polar Gastro Single Door Upright	42	AB868	Condenser for G593
CW197/G592/G593 - Polar Gastro Single Door Upright	43		Capillary
CW197/G592/G593 - Polar Gastro Single Door Upright	44	AB120	Filter Drier
CW197/G592/G593 - Polar Gastro Single Door Upright	45	AH311	Front Panel Fixed Clip
CW197/G592/G593 - Polar Gastro Single Door Upright	46	AH317	Right LED Lamp for CW197
CW197/G592/G593 - Polar Gastro Single Door Upright	47	AH318	Left LED Lamp for CW197
CW197/G592/G593 - Polar Gastro Single Door Upright	48	AH308	Floor Protector Shelf
CW197/G592/G593 - Polar Gastro Single Door Upright	49	AH319	LED Transformer for CW197