




Machine	Explode	Code	Description
Polar Patisserie Display - 400Ltr	1.		Top corner
Polar Patisserie Display - 400Ltr	2.		Top board
Polar Patisserie Display - 400Ltr	3.	AE809	Upper hinge
Polar Patisserie Display - 400Ltr	4.	AE810	Door hinge fixer
Polar Patisserie Display - 400Ltr	5.		Body corner frame
Polar Patisserie Display - 400Ltr	6.		Glass door
Polar Patisserie Display - 400Ltr	7.	AE811	Door handle
Polar Patisserie Display - 400Ltr	8.		Support
Polar Patisserie Display - 400Ltr	9.		Back of support
Polar Patisserie Display - 400Ltr	10.		Support bar reinforcement
Polar Patisserie Display - 400Ltr	11.		Shelf clip rail
Polar Patisserie Display - 400Ltr	12.	AD413	Shelf clip
Polar Patisserie Display - 400Ltr	13.	AE812	Shelf
Polar Patisserie Display - 400Ltr	14.		Support fixer
Polar Patisserie Display - 400Ltr	15.	AE813	Down hinge axis
Polar Patisserie Display - 400Ltr	16.	AB339	Circuit fan
Polar Patisserie Display - 400Ltr	17.		Nut
Polar Patisserie Display - 400Ltr	18.	AE814	Condenser
Polar Patisserie Display - 400Ltr	19.	AB309	Condenser fan
Polar Patisserie Display - 400Ltr	20.		Discharge pipe
Polar Patisserie Display - 400Ltr	21.	AE815	Water box
Polar Patisserie Display - 400Ltr	22.	AA658	Basket guard grills
Polar Patisserie Display - 400Ltr	23.	AA806	Compressor
Polar Patisserie Display - 400Ltr	24.		Evaporator
Polar Patisserie Display - 400Ltr	25.	AE816	Braked castor
Polar Patisserie Display - 400Ltr	26.		Body
Polar Patisserie Display - 400Ltr	27.		Unit Board
Polar Patisserie Display - 400Ltr	28.		Right Panel
Polar Patisserie Display - 400Ltr	29.		Front Panel
Polar Patisserie Display - 400Ltr	30.		Ventilation panel fixer
Polar Patisserie Display - 400Ltr	31.	AB308	Main switch
Polar Patisserie Display - 400Ltr	32.	AB363	Thermostat
Polar Patisserie Display - 400Ltr	34.		Left Panel
Polar Patisserie Display - 400Ltr	35.		Rear panel
Polar Patisserie Display - 400Ltr	36.		Front Base panel
Polar Patisserie Display - 400Ltr	37.		Base panel cover
Polar Patisserie Display - 400Ltr	38.		Rear base panel
Polar Patisserie Display - 400Ltr	39.	AE817	LED Lamp
Polar Patisserie Display - 400Ltr	40.	AE818	Un-braked castor
Polar Patisserie Display - 400Ltr	41.	AE819	Gasket
Polar Patisserie Display - 400Ltr	42.	AE820	Fan blades
Polar Patisserie Display - 400Ltr	43.		Circuit fan support
Polar Patisserie Display - 400Ltr	44.	AA638	Drain pipe cover
Polar Patisserie Display - 400Ltr	45.	AA637	Drain pipe
Polar Patisserie Display - 400Ltr	46.	AA639	Sensor fixed clip