




Machine	Explode	Code	Description
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	1	AA220	Bottom Panel
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	2	AA107	Ice Scoop
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	3	AA222	Switch Panel
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	4	AA223	Upper Panel
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	5	AA224	PVC Cover
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	6	AA102	Indicator Panel
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	7	AA226	On-off Switch
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	11	AA230	Upper Edge Panel
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	12		Operation Panel Cover
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	13		Right Panel
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	14	AA233	Control Box
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	16		Control Box Cover
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	15	AA234	Control Board(R134a)
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	15	AG871	Control Board(R600a)
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	18	AA237	Water Shower
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	20	AA239	Water Box
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	21	AA240	Evaporator Fixer
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	22	AA241	Rinsing Connector
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	23		Top Panel
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	24	AA129	Water Level Sensor
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	25	AA244	Water Temperature Sensor
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	30	AA249	Water Inlet head
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	31	AA250	Water Filling Tube
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	33	AA252	Alnico
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	36	AE947	Motor Connecting Axis AA119 (short axis)
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	70		Motor Guide
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	71		Tray Motor(with long axel)
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	37	AA256	Big Washer
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	38	AA257	Butterfly Shape Washer
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	40	AA115	Stopper
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	41	AA260	Diffused Device
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	42		Evaporator
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	43		Cabinet Liner
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	44	AA263	Magnet Valve
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	46	AA265	Water Inlet Valve
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	47	AA266	Water Valve Fixer
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	48	AA267	Filter
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	49	AA268	Steel Grill
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	50		Left Panel
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	51		Grill
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	52	AA271	Compressor(R134a)
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	52	AG872	Compressor(R600a)
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	53		Condenser
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	54	AA273	Fan
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	56		Compressor Fixing Board

T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	57	AA276	Feet
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	61	AB096	Rubber Foot
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	58	AA244	Ice Level Sensor
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	59	AA278	Ice Level Sensor Fixer
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	60	AA279	Ice Flopping Shelf
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	62	AE695	WRAS Approved Hose
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	63	AE941	Water Recycling Tube
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	64	AA560	Pump(Model:TP-450)
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	65	AE943	Pump Connector
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	66	AE944	Water Shower Cover
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	67	AE945	Hall Device
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	68	AE946	Motor Fixing Panel
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	69	AH060	Axis Cover
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	72		Back Panel
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	73		Power Cord
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	74	AE948	Water Inlet Tube
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	75	AE950	Waste Water Discharge Tube
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	76		Water Discharge Tri-Connector
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	77	AE950	Icing Water Discharge Tube
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	78		Wiring Tube
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	79		Drainage Cover
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	80	AE699	Seal Washer For Drainage Connector
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	81	AH061	Discharged Elbow Connector
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	82		Metal Bracket
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	83	AE951	Ambient Temp Sensor
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	84		Mirco Switch
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	85		Mirco Switch Board
T316 - Polar Mains-Fill Ice Cube Maker - 20kg/24hr	86		Plastic Upper Fixing Board