




Machine	Explode	Code	Description
GL187 - Polar werkbank koeling 6 laden	1		Front Panel Hinge Down
GL187 - Polar werkbank koeling 6 laden	2		Front Panel Lock Hook
GL187 - Polar werkbank koeling 6 laden	3		Front Panel
GL187 - Polar werkbank koeling 6 laden	4		Thermostat Cover
GL187 - Polar werkbank koeling 6 laden	5		Front Panel Hinge Up
GL187 - Polar werkbank koeling 6 laden	6		Evaporator Cover Left
GL187 - Polar werkbank koeling 6 laden	7		Lamp Switch
GL187 - Polar werkbank koeling 6 laden	8		Probe Padding
GL187 - Polar werkbank koeling 6 laden	9		Sensor Fixed Clip
GL187 - Polar werkbank koeling 6 laden	10		Air Flow Conduct Board Left
GL187 - Polar werkbank koeling 6 laden	11		Evaporator Fixed Board Front
GL187 - Polar werkbank koeling 6 laden	12		Fan Fixed Board
GL187 - Polar werkbank koeling 6 laden	13		Evaporator Fan
GL187 - Polar werkbank koeling 6 laden	14		Evaporator Water Pan
GL187 - Polar werkbank koeling 6 laden	15		Evaporator
GL187 - Polar werkbank koeling 6 laden	16		Evaporator Fixed Board Back
GL187 - Polar werkbank koeling 6 laden	17		Air Flow Conduct Right
GL187 - Polar werkbank koeling 6 laden	18		Evaporator Cover Right
GL187 - Polar werkbank koeling 6 laden	19		Unit Room Cover
GL187 - Polar werkbank koeling 6 laden	20		Plug
GL187 - Polar werkbank koeling 6 laden	21		Thermostat Support
GL187 - Polar werkbank koeling 6 laden	22		Thermostat
GL187 - Polar werkbank koeling 6 laden	23		Main Switch
GL187 - Polar werkbank koeling 6 laden	24		Discharge Pipe
GL187 - Polar werkbank koeling 6 laden	25		Water Box
GL187 - Polar werkbank koeling 6 laden	26		Condenser
GL187 - Polar werkbank koeling 6 laden	27		Suction Pipe
GL187 - Polar werkbank koeling 6 laden	28	AB339	Condenser Fan
GL187 - Polar werkbank koeling 6 laden	29	AG014	Compressor(R600a)
GL187 - Polar werkbank koeling 6 laden	32		Unit Board
GL187 - Polar werkbank koeling 6 laden	34		Body
GL187 - Polar werkbank koeling 6 laden	35		Feet
GL187 - Polar werkbank koeling 6 laden	36		Adjust Bolt
GL187 - Polar werkbank koeling 6 laden	37		Back Support Right
GL187 - Polar werkbank koeling 6 laden	38		Front Support Right
GL187 - Polar werkbank koeling 6 laden	39		Back Support Left
GL187 - Polar werkbank koeling 6 laden	40		Front Support Left
GL187 - Polar werkbank koeling 6 laden	41		Down Drawer Panel
GL187 - Polar werkbank koeling 6 laden	42		Guide Left
GL187 - Polar werkbank koeling 6 laden	43		Guide Right
GL187 - Polar werkbank koeling 6 laden	44		Drawer Body
GL187 - Polar werkbank koeling 6 laden	45		Drawer Gasket

GL187 - Polar werkbank koeling 6 laden	46		Screw
GL187 - Polar werkbank koeling 6 laden	47		Washer
GL187 - Polar werkbank koeling 6 laden	48		Lock Hook
GL187 - Polar werkbank koeling 6 laden	49		Bridge
GL187 - Polar werkbank koeling 6 laden	50		Up Drawer Panel
GL187 - Polar werkbank koeling 6 laden	N/A	AG960	Filter Drier
GL187 - Polar werkbank koeling 6 laden	N/A	AC614	Sensor